MBR



MULTI-POSITION, MULTI-SPEED MODULAR BLOWER WITH PSC MOTOR



Contents

Air Handler Nomenclature	2
Heater Kit Nomenclature	2
Product Specifications	3
Dimensions	4
Airflow Data	5
Heat Kit Data	6
Wiring Diagram	7

Product Features

- Direct drive, multi-speed PSC blower motor
- Cooling or heat pump applications: upflow, downflow, and horizontal
- Blower section usable as an electric furnace
- Control board includes a fan delay in the cooling mode and is isolated from the air stream
- Intended for use with CAPF/ CHPF cased evaporator coils
- CAPF/CHPF coils are equipped with a check flowrater
- AHRI certified; ETL listed

- Painted, galvanized steel cabinet
- Horizontal or vertical configuration capabilities
- 21" depth for easier attic access
- Foil-faced insulation is glued in place and covers the entire blower case to reduce operating sound and cabinet condensation
- Galvanized, leather grain-embossed finish
- 3 kW 21 kW electric heat kits available
- Cabinet air leakage less than 2% at 1.0 inch H₂0 when tested in accordance with ASHRE standard 193
- Cabinet air leakage less than 1.4% at 0.5 inch H₂0 when tested in accordance with ASHRE standard 193









COMPANY WITH QUALITY SYSTEM CERTIFIED BY DNV 0 = ISO 9001 = COMPANY WITH ENVIRONMENTAL SYSTEN CERTIFIED BY DNV GL = ISO 14001=

^{*} Complete warranty details available from your local dealer or at www.amana-hac.com.

To receive the 10-Year Parts Limited Warranty, online registration must be completed within 60 days of installation. Online registration is not required in California or Québec.






Model	MBR0800AA-1	MBR1200AA-1	MBR1600AA-1	MBR2000AA-1	
BLOWER					
Diameter	9"	9"	10"	10"	
Width	6"	6" 8" 8"		10"	
ELECTRICAL DATA					
Voltage	208 / 230	208/230	208 / 230	208 / 230	
Min Circuit Ampacity	1.9	2.3	3.8	4.9	
Max. Overcurrent Device (Amps)	15	15	15	15	
BLOWER MOTOR					
Horsepower (HP)	1/4	1/3	⅓	1/2	
Ship Weight (Lbs.)	62	62	73	84	

[•] Minimum Circuit Ampacity (MCA) and Maximum Overcurrent Protection (MOP) for blower without supplemental heat installed. Refer to unit nameplate for these specifications with approved accessory heaters installed.


[•] Condensate management kits are available for units installed in high temperature and high humidity areas through the Service Parts Department. For MBR0800 and MBR1200, please order kit number MBK0001, and for MBR1600 and MBR2000, please order kit number MBK0002 to resolve condensate issues in the field. Refer to IO-849 for installation instructions.

SIDE AND FRONT VIEWS



	w	н	D
MBR0800*	17½"	26"	21"
MBR1200*	17½"	26"	21"
MBR1600*	21"	30"	21"
MBR2000*	24½"	30"	21"

TOP VIEW



Speed	STATIC	MBR0800**-* SCFM	MBR1200**-* SCFM	MBR1600**-* SCFM	MBR2000**-* SCFM	
	0.1	1,240	1,500	1,800	2,160	
	0.2	1,170	1,460	1,740	2,080	
High	0.3	1,120	1,360	1,680	1,990	
High	0.4	1,060	1,280	1,610	1,890	
	0.5	980	1,200	1,520	1,790	
	0.6	900	1,110	1,430	1,690	
Medium	0.1	900	1,380	1,540	1,730	
	0.2	850	1,320	1,490	1,670	
	0.3	790	1,270	1,450	1,590	
	0.4	740	1,200	1,400	1,520	
	0.5	680	1,140 1,350		1,420	
	0.6	605	1,040	1,280	1,320	
	0.1	650	1,170	1,130	1,520	
	0.2	590	1,130	1,100	1,450	
Low	0.3	540	1,080	1,070	1,360	
	0.4	500	1,020	1,030	1,290	
	0.5	430	950	990	1,200	
	0.6	330	830	930	1,090	

Notes

- The chart is for information only. For satisfactory operation, external static pressure must not exceed value shown on rating plate.
- Use the CFM adjustment factors of .98 for horizontal left, .95 for horizontal right & .96 for downflow orientations.

	Circuit 1			CIRCUIT 2			SINGLE-POINT KIT	
MODELS	HEATER AMPS	MCA ¹	MOP ²	HEATER AMPS	MCA ¹	MOP²	MCA ¹	MOP ²
MBR0800AA-1 **	0/0	1.9 / 1.9	15 / 15					
HKR-03*	10.8 / 12.5	15.4 / 18	20 / 20					
HKR-05* / 05C*	17.2 / 19.8	23 / 27	25 / 30					
HKR-06*	21.7 / 25.0	29 / 33	30 / 35					
HKR-08* / -08C*	25.3 / 29.2	33 / 38	35 / 40					
MBR1200AA-1 **	0/0	2.3 / 2.3	15 / 15					
HKR-03*	10.8 / 12.5	15.8 / 18	20 / 20					
HKR-05* / 05C*	17.2 / 19.8	24 / 27.1	25 / 30					
HKR-06*	21.7 / 25.0	29.4 / 34	30 / 35					
HKR-08* / -08C*	25.3 / 29.2	33.9 / 39	35 / 40					
HKR-10* / -10C*	34.3 / 39.6	45.2 / 52	50 / 60					
HKA-15C*	34.3 / 39.6	45.2 / 52	50 / 60	17.2 / 19.8	21 / 25	25 / 25	67/77	70 / 80
HKA-20C*	34.3 / 39.6	45.2 / 52	50 / 60	34.3 / 39.6	43 / 49	45 / 50	89/102	90 / 110
^HKR3-15*	0/0	2.3 / 2.3	15 / 15	31.3 / 36.1	39 / 45.1	40 / 50		
^HKR3-20*	0/0	2.3 / 2.3	15 / 15	40.7 / 46.9	51/59	60 / 60		
MBR1600AA-1 **	0/0	3.8 / 3.8	15 / 15					
HKR-03*	10.8 / 12.5	17 / 19	20 / 20					
HKR-05* / 05C*	17.2 / 19.8	25.2 / 28	30/30					
HKR-06*	21.7 / 25.0	31/35	35 / 35					
HKR-08* / -08C*	25.3 / 29.2	35.3 / 40.2	40 / 45					
HKR-10* / -10C*	34.3 / 39.6	47 / 53	50 / 60					
HKA-15C*	34.3 / 39.6	47 / 53	50 / 60	17.2 / 19.8	21 / 25	25 / 25	68/78	70 / 80
HKA-20C*	34.3 / 39.6	47 / 53	50 / 60	34.3 / 39.6	43 / 49	45 / 50	90/103	90 / 110
^HKR3-15*	0/0	3.8 / 3.8	15 / 15	31.3 / 36.1	39 / 45.1	60 / 60		
^HKR3-20*	0/0	3.8 / 3.8	15 / 15	40.7 / 46.9	51/59	60 / 60		
MBR2000AA-1 **	0/0	4.9 / 4.9	15 / 15					
HKR-03*	10.8 / 12.5	18 / 21	20 / 25					
HKR-05* / 05C*	17.2 / 19.8	26/30	30 / 35					
HKR-06*	21.7 / 25.0	32 / 36	35 / 40					
HKR-08* / -08C*	25.3 / 29.2	36.5 / 41	40 / 45					
HKR-10* / -10C*	34.3 / 39.6	47.8 / 54	50 / 60					
HKA-15C*	34.3 / 39.6	47.8 / 54	50 / 60	17.2 / 19.8	21 / 25	25 / 25	69/79	70 / 80
HKA-20C*	34.3 / 39.6	47.8 / 54	50 / 60	34.3 / 39.6	43 / 49	45 / 50	91/104	100 / 110
^HKR3-15*	0/0	4.9 / 4.9	15 / 15	31.3 / 36.1	39 / 45.1	40 / 50		
^HKR3-20*	0/0	4.9 / 4.9	15 / 15	40.7 / 46.9	51/59	60 / 60		

All ampacities noted above include air handler motor amps

Circuit 1: Single-phase for Air Handlers / Circuit 2: Three-phase for HKR3 Heater Kits


C = Circuit Breaker Option


- --- indicates Not Required
- Only applicable when HKA kits are included in table HKA meets the new UL1995 requirements for 15 and 20KW heaters
- MBVC and MBR models

¹ Minimum Circuit Ampacity (Heater Amps + Motor Amps) X 1.25

² Maximum Overcurrent Protection = 2.25 X Motor Amps + Heater Amps

st Revision level that may or may not be designated






Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.



High Voltage: Disconnect all power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury, or death.





Wiring is subject to change. Always refer to the wiring diagram on the unit for the most up-to-date wiring.



High Voltage: Disconnect all power before servicing or installing this unit. Multiple power sources may be present. Failure to do so may cause property damage, personal injury, or death.

